


Hitachi CP-S240 LCD Projector

Dual Purpose Port

RGB IN2 - Use this port to connect your document camera or computer to the projector.

RGB OUT - Use this port to connect a monitor to the projector.

RGB IN2/OUT BUTTON - Use this button to switch the RGB IN2/OUT port the signal direction between RGB IN to RGB OUT.



CABLE LOCK SLOT - Connect locking cable here.

RGB IN1 - Use this port to connect your document camera or computer to the projector. Note: The blue color of this port matches a similar color port on the back of some computers.


AUDIO OUT Port - For better sound connect a pair of computer speakers to this port when using a VCR or DVD with the projector.

RCA AUDIO IN PORTS

- Left (White)/Right (Red) - Use to connect VCR or DVD sound to the projector's internal speakers.



RCA VIDEO IN PORT (Yellow)

- Use to connect a video camera, VCR, or DVD to the projector using RCA cables.





S-VIDEO IN PORT - Use to directly connect a video camera or TV to the projector using an S-Video cable.

Hitachi LCD Projector



ON/OFF SWITCH -
 "I" switches on the projector power.
 "O" switches off the projector power.

POWER CORD CONNECTION



SECURITY BAR - Use for looping securing cable through.